

## 统计选择集



**comboBoxFields** System.Windows.Forms.ComboBox  
**comboBoxLayers** System.Windows.Forms.ComboBox  
**FormStatistics** System.Windows.Forms.Form  
**groupBox1** System.Windows.Forms.GroupBox  
**label1** System.Windows.Forms.Label  
**label2** System.Windows.Forms.Label  
**labelSelection** System.Windows.Forms.Label  
**labelStatisticsResult** System.Windows.Forms.Label

```
using System;
using System.Collections.Generic;
using System.ComponentModel;
using System.Data;
using System.Drawing;
using System.Linq;
using System.Text;
using System.Windows.Forms;
using System.Collections;

using ESRI.ArcGIS.Carto;
using ESRI.ArcGIS.Geodatabase;
using ESRI.ArcGIS.esriSystem;

namespace GIS2022
{
    public partial class FormStatistics : Form
    {
        private IMap currentMap;      //当前MapControl控件中的Map对象
        //设置哈希表类型的类变量来存储图层名称和所对应矢量图层的IFeatureLayer接口对象
        private Hashtable layersHashtable;
        //设置类变量存储当前的矢量图层对象
        private IFeatureLayer currentFeatureLayer = null;

        /// <summary>
        /// 获得当前MapControl控件中的Map对象。
        /// </summary>
        public IMap CurrentMap
    }
```

```

    set
    {
        currentMap = value;
    }
}

public FormStatistics()
{
    InitializeComponent();
    //新建哈希表对象
    layersHashtable = new Hashtable();
}

private void FormStatistics_Load(object sender, EventArgs e)
{
    IFeatureLayer featureLayer; //设置临时变量存储矢量图层对象
    string layerName; //设置临时变量存储图层的名称
    int layersCount = 0; //设置临时变量存储具有选择要素的图层总个数
    int allSelectedFeatures = 0; //设置临时变量存储被选择要素的总数

    //清空哈希表
    layersHashtable.Clear();

    //对Map中的每个图层进行判断和加载名称
    for (int i = 0; i < currentMap.LayerCount; i++)
    {
        //如果该图层为图层组类型，则分别对所包含的每个图层进行操作
        if (currentMap.get_Layer(i) is GroupLayer)
        {
            //使用ICompositeLayer接口进行遍历操作
            ICompositeLayer compositeLayer = currentMap.get_Layer(i) as ICompositeLayer;
            for (int j = 0; j < compositeLayer.Count; j++)
            {
                //得到图层的名称
                layerName = compositeLayer.get_Layer(j).Name;
                //得到IFeatureLayer接口的矢量图层对象
                featureLayer = (IFeatureLayer)compositeLayer.get_Layer(j);
                //通过接口转换获得当前图层选择集中被选择要素的总数，如果大于0则进行统计
                if (((IFeatureSelection)featureLayer).SelectionSet.Count > 0)
                {
                    //在comboBoxLayers中添加该图层的名称
                    comboBoxLayers.Items.Add(layerName);
                    //在哈希表中添加一项，包括图层名称和图层对象
                    layersHashtable.Add(layerName, featureLayer);
                    //具有选择要素的图层总个数加1
                    layersCount += 1;
                    //被选择要素的总数加上被选择要素的数量
                    allSelectedFeatures +=
((IFeatureSelection)featureLayer).SelectionSet.Count;
                }
            }
        }
    }
}

```

```

        }
    }

}

//如果图层不是图层组类型，则直接执行操作
else
{
    layerName = currentMap.get_Layer(i).Name;
    featureLayer = (IFeatureLayer)currentMap.get_Layer(i);
    if (((IFeatureSelection)featureLayer).SelectionSet.Count > 0)
    {
        comboBoxLayers.Items.Add(layerName);
        layersHashtable.Add(layerName, featureLayer);
        layersCount += 1;
        allSelectedFeatures += ((IFeatureSelection)featureLayer).SelectionSet.Count;
    }
}
}

//将当前的选择情况显示在窗体上
labelSelection.Text = "当前地图选择集共有 " + layersCount + " 个图层的 " +
allSelectedFeatures + " 个要素被选中。";

//显示第一个可以选择的图层
if (comboBoxLayers.Items.Count > 0)
    comboBoxLayers.SelectedIndex = 0;
}

//当所选择图层发生变化时触发事件，执行本函数
private void comboBoxLayers_SelectedIndexChanged(object sender, EventArgs e)
{
    //将comboBoxFields控件清空
    comboBoxFields.Items.Clear();

    //对哈希表进行遍历
    foreach (DictionaryEntry de in layersHashtable)
    {
        //如果哈希表中某项的Key值是所选择的图层名称
        if (de.Key.ToString() == comboBoxLayers.SelectedItem.ToString())
        {
            //将该项Value值赋值给当前的矢量图层对象
            currentFeatureLayer = de.Value as IFeatureLayer;
            break;
        }
    }
}

//定义并得到当前矢量图层的全部字段信息
IFields iFields;
iFields = currentFeatureLayer.FeatureClass.Fields;
IField field;

```

```

//对所有字段进行遍历
for (int i = 0; i < iFields.FieldCount; i++)
{
    //根据索引得到字段
    field = iFields.get_Field(i);
    //如果字段名称不为"OBJECTID"或 "SHAPE"
    if (field.Name.ToUpper() != "OBJECTID" && field.Name.ToUpper() != "SHAPE")
    {
        //如果字段类型为可以进行统计的数值类型，则将该字段添加到comboBoxFields中
        if (field.Type == esriFieldType.esriFieldTypeInteger || field.Type ==
esriFieldType.esriFieldTypeDouble
        || field.Type == esriFieldType.esriFieldTypeSingle || field.Type ==
esriFieldType.esriFieldTypeSmallInteger)
            comboBoxFields.Items.Add(field.Name);
    }
}

//显示第一个可以选择的字段
if (comboBoxFields.Items.Count > 0)
    comboBoxFields.SelectedIndex = 0;
}

//当选择统计字段发生变化时触发事件，执行本函数，完成统计分析操作
private void comboBoxFields_SelectedIndexChanged(object sender, EventArgs e)
{
    //定义及新建IDataStatistics接口的对象进行字段统计
    IDataStatistics dataStatistics = new DataStatisticsClass();
    //获取需要统计的字段
    dataStatistics.Field = comboBoxFields.SelectedItem.ToString();
    //将当前矢量图层对象进行接口转换以进行选择集操作
    IFeatureSelection featureSelection = currentFeatureLayer as IFeatureSelection;
    //定义选择集的游标
    ICursor cursor = null;
    //使用null参数的Search方法获取整个选择集中的要素，得到相应的游标
    featureSelection.SelectionSet.Search(null, false, out cursor);
    //将该游标赋值给IDataStatistics接口对象的游标
    dataStatistics.Cursor = cursor;
    //执行统计
    IStatisticsResults statisticsResults = dataStatistics.Statistics;
    //定义StringBuilder对象进行字符串的操作
    StringBuilder stringBuilder = new StringBuilder();
    //以下语句依次增加各类统计结果
    stringBuilder.AppendLine("统计总数: " + statisticsResults.Count.ToString() + "\n");
    stringBuilder.AppendLine("最小值: " + statisticsResults.Minimum.ToString() + "\n");
    stringBuilder.AppendLine("最大值: " + statisticsResults.Maximum.ToString() + "\n");
    stringBuilder.AppendLine("总计: " + statisticsResults.Sum.ToString() + "\n");
    stringBuilder.AppendLine("平均值: " + statisticsResults.Mean.ToString() + "\n");
    stringBuilder.AppendLine("标准差: " + statisticsResults.StandardDeviation.ToString());
    //将统计结果显示在窗体中
}

```

```
        labelStatisticsResult.Text = stringBuilder.ToString();
    }
}
}
```

主窗体代码：

```
private void 选择集统计ToolStripMenuItem_Click(object sender, EventArgs e)
{
    //新创建统计窗体
    FormStatistics formStatistics = new FormStatistics();
    //将当前主窗体中MapControl控件中的Map对象赋值给FormStatistics窗体的CurrentMap属性
    formStatistics.CurrentMap = mainMapControl.Map;
    //显示统计窗体
    formStatistics.Show();
}
```